

Gtechniq Crystal Serum Light - Application Information

Storage and Use

- To apply Crystal Serum Light (CSL) make sure your vehicle is indoors and can stay indoors for 12 hours after application, do not apply in direct sunlight
- Only apply the product at a temperature between 5°C and 25°C
- Shake well and wear gloves
- Wash and decontaminate your paintwork thoroughly prior to application. If required, polish your paintwork, either by machine or hand, to remove any imperfections
- Spray Panel Wipe onto a Gtechniq MF1 Microfibre Cloth and wipe down each panel in small sections
- Soak the application pad with 3 full measures of CSL from the pipette and work the liquid into the pad to get an even saturation
- Replace the lid on the bottle and set aside - do not keep the bottle in your hand as this promotes premature curing
- Apply in overlapping strokes to an area roughly 2ft by 2ft (60cm by 60cm), or work to the bodylines of the vehicle
- After approximately 10 to 15 seconds remove the residue with a Gtechniq MF1 Cloth - you may need to buff the same area several times, however, avoid doing it with too much force. We recommend the use of 2 cloths at any one time. Make sure the cloths are rotated during residue removal to prevent CSL curing in the cloth - this can make buffing residue difficult
- Inspect the surface for excess residue with a bright, diffused light source
- If you do not remove all the excess residue and it cures fully then you should polish the area and reapply CSL
- As soon as you finish, put your MF1 cloths in water, wash and dry them as soon as possible - never re-use an already used MF1 cloth for ceramic coatings
- If you are overcoating CSL with EXO then wait a minimum of 1 and a maximum of 12 hours after you have applied CSL to apply EXO Ultra Durable Hydrophobic Coating, or C2v3 Ceramic Sealant
- An unopened bottle of Crystal Serum Light has a 12-month Shelf life from the time of purchase. As soon as a bottle is open it needs to be used within 1 week - the pipette must be removed, cleaned and the cap replaced. The Product must be stored in a cool, dry place
- Use within 3 months of opening
- Refer to the Gtechniq Australia YouTube channel for all of our how to apply videos:-



Scan here:-